



## Charging Your Tablet

1



Plug the USB cable into the USB charging base.

2



Plug the USB cable into the device's USB port.


 $\bf 3$  Plug the USB charging base into an electric socket.

#### Tablet charging tips


- The battery icon will appear empty when the battery is low.
- The battery icon will contain a lightning bolt when it is charging.
- If the tablet is turned off and the battery is fully drained, the tablet may need to charge for several minutes before it's charged enough to turn on.
- If the charging power source is unstable, the tablet's touch screen may stop working. Unplug the tablet from the power source.
- The tablet will heat up while charging. If the device starts to overheat a warning will appear and it may shut itself off. You'll be able to turn it back on once its cooled down.
- Keep the tablet plugged in and charging for ease of use.





## Connect Your Tablet to WiFi




Wait about a minute for the tablet to turn on









Enter the network password and tap the Connect Button




6

The connected network will be in the Current Network section





If your tablet does not have a physical Home Button, swipe up from the bottom of the screen to reveal the Navigation Bar




Press the Home Button to return to the Home Screen




# Launching the Onset Assistant Application

A WiFi symbol in the Status Bar indicates that the tablet is connected to a network




If the tablet is not connected to a WiFi network open the Network Settings and connect to one




First the application will connect your tablet to the server



Then your tablet will be synced with the other connected tablets




After connecting and syncing you will be able to select a user or create a new one




#### ONSET

# Closing the Onset Assistant Application



If your tablet has a physical Home Button, press the ☐ icon below it


If your tablet does not have a physical Home button, pull up from the bottom of the screen to reveal the Navigation Bar







You will be shown the applications that are running



Flick the application up to close it

1<sub>b</sub>

5/5